

Universele Fendt tochtstrook

Universelle Fendt Windblende
Universal Fendt draught screen



NL Benodigdheden

Schaar, pen of potlood en secondelijm

DE Sie benötigen

Schere, Stift oder Bleistift und Sekundenkleber

UK You will need

Scissors, pen or pencil and superglue



NL Schuif de tochtstrook door de rails van de caravan, zorg dat de uitsparing van de tochtstrook goed onder de deur zit **(A)**. Teken links en rechts van de tochtstrook het einde af met een pen of potlood **(B)**. Knip in een rechte verticale lijn naar beneden de tochtstrook af. Doe een klein druppeltje seconden lijm of de door geknipte garen. Deur rechts? Draai de tochtstrook om.



DE Schieben Sie die Windblende durch die Schienen des Wohnwagens, achten Sie darauf, dass sich die Aussparung der Windblende richtig unter der Tür befindet **(A)**. Zeichnen Sie das Ende links und rechts von der Windblende mit einem Kugelschreiber oder Bleistift **(B)**. Schneiden Sie die Windblende in einer geraden vertikalen Linie nach unten. Geben Sie einen kleinen Tropfen Sekundenkleber oder das geschnittene Garn. Tür rechts? Drehen Sie die Windblende um.

UK Slide the draft screen through the rails of the caravan, make sure that the recess of the draft screen is properly under the door **(A)**. Draw the end of the left and right side of the draft screen with a pen or pencil **(B)**. Cut down the draft screen in a straight vertical line. Put a small drop of superglue or the cut yarn. Door right? Turn the draft screen around.